



## Installation Instructions

- 1) Dig an adequate hole in the ground (up to 24" deep depending on soil type) and set the trunk in the hole and surround with concrete and allow to set up.
  - 2) After the concrete has set up insert the palm fronds. The steel inserts of the fronds have been color coded to correspond to their respective slots in the mounting cap on top of the tree trunk.
    - a) First insert the 3 fronds with the "Black" tips into the Black slots.
    - b) Next insert the 3 "White" tipped fronds into the White slots.
- \*\*Adjust the fronds up or down to suit your taste by bending them up or down while they are in the tree.**
- 3) Hang the 2 coconuts into the looped wire just beneath the fronds.



All fronds will stick straight up when inserted. Now it's time to bend them down into place.



Bend the BLACK tipped fronds down so that they are lower than the top of the trunk.



Bend the WHITE tipped fronds down just slightly to about a 45 degree angle. This will give your palm tree a very natural look.

